

Instructions for Mounting Primitive™ Subaru Snow Shield for 2015+ Outback:

Hardware:

- ✓ Only factory hardware is required, reuse the “push-plugs”
 - a) Remove Packaging and any Protective wrapping from your new skidplate, and unfold the black, plastic snow shield and put a book on it overnight to flatten back out after shipping.
 - b) Raise the car securely on jack stands or ramps. Remove the five corresponding body pins on the under-cladding of the car. You do this to remove the factory splash shield and to install the aluminum front skidplate. Retain those push plugs, you will re-use them.
 - c) Put the snow shield in place as pictured and reinstall the plastic plugs to secure it.

