

## Primitive Racing Brake Line Extender Brackets

What's in the box: qty = 2 brake line extension brackets, qty = 2 M8x1.25 20mm bolts and matching washers

Step 1 – With the vehicle on jack stands, remove the rear wheels.

Step 2 – Locate where the brake line attaches to the rear knuckle and remove the 12mm bolt. Set aside bolt for use in step 3.

Step 3 – With the rounded end facing down bolt the brake line extender in-place of the factory line and secure using the 12mm bolt we set aside in step 2. Tighten to 12 ft lbs.

Step 4 – Set the brake line into the rounded notch and bolt into place using the supplied 20mm bolt and washer. Angle the bracket away from wheel just a little bit. Tighten bolt to ~12 ft lbs.

Step 5 – Re-install wheels and check for clearance. Don't forget to torque your lug nuts!

**Thank you!**

