

Instructions for Mounting Primitive™ Subaru front skidplate for 2010-17 Outback:

- a) 2010-14: Remove existing black plastic undertray: 2 - 12mm headed bolts, 4 - plastic pushpins and 6 plastic screw pins.
- b) 2015-17: Remove existing black plastic splash shield: 3 - 12mm headed bolts and 16 plastic pushpins. You'll also need to remove the 12mm headed bolt next to the rearmost bolt attaching the stock splash shield, this bolt is dead center on the car and is where the rear of the skidplate attaches.
- c) Remove packaging and any protective coating from new skidplate, locate assembly hardware.
- d) 2 bolts and washers will go where the two 12mm headed bolts were removed in step a).
- e) 1 remaining bolt and washer will go through the rear hole into the subframe.
- f) Hold up skidplate under engine, with rectangular hole around the front jack up pad.
- g) Start rear bolt first then insert the two push pins on both sides of the jack up pad, install remaining two bolts and finish by tightening all hardware to approx 11-14 ft/lbs with a 13mm socket or wrench.

www.get-primitive.com