

Instructions for Mounting Primitive front skidplate for 2018-2019 Subaru Outback:

- 1) Remove existing black plastic splash shield: 3 - 12mm headed bolts and 16 plastic pushpins. You'll also need to remove the 12mm headed bolt next to the rearmost bolt attaching the stock splash shield, this bolt is dead center on the car and is where the rear of the skidplate attaches.
- 2) Remove packaging and any protective coating from new skidplate, locate assembly hardware.
- 3) 2 bolts and washers will go where the two 12mm headed bolts removed in step a came from.
- 4) 1 remaining bolt and washer will go through the rear hole into the subframe, removed in the second half of step 1.
- 5) Hold up skidplate under engine, with rectangular hole around the front jack up pad.
- 6) Start rear bolt first then install the remaining two bolts and finish by tightening all hardware to 11-14 ft/lbs with a 13mm socket or wrench.

DO NOT OVERTIGHTEN!!!!

www.get-primitive.com